

ASSEMBLY INSTRUCTIONS

MIRROR ADAPTERS HONDA CBR 1000 RR

HP-ADATT

KIT

- X1. SPECIFIC PLATES KIT (LEFT + RIGHT)
- X4. M6X40 HEX HEAD ALLEN SCREW
- X4. Ø6 KNURLED NUT
- X4. H 4.5MM SPECIFIC THICKNESS

WWW.BARRACUDAMOTO.COM

ASSEMBLY PROCEDURE:

1. REMOVE THE ORIGINAL MIRRORS, TAKING CARE NOT TO DAMAGE THE ELECTRICAL CONNECTIONS.
2. MOUNT THE SPECIFIC PLATES AND THE BRACKET OF THE BARRACUDA MIRRORS USING THE M6X40 HEX HEAD ALLEN SCREW, THE SPECIFIC THICKNESSES AND THE KNURLED NUTS, AS SHOWN.
3. RESTORE THE ELECTRICAL CONNECTIONS AND TIGHTEN EVERYTHING.

